



ECO ETS – ASSEMBLY BUDDY

AUTOMATIC SWING DOOR DRIVE

■ SYSTEM TECHNOLOGY FOR THE DOOR




ELECTROMOTIVE SWING DOOR DRIVES ECO ETS

Single-leaf swing door drives ■ for standard and external doors


Types of doors



Tests / standards



ETS 42
(EN 2 – 4)



ETS 73
(EN 3 – 7)

Single-leaf swing door drives ■ for fire and smoke protection doors


Types of doors



Tests / standards



ETS 42-R¹⁾
(EN 2 – 4)



ETS 64-R
(EN 3 – 6)

Single-leaf swing door system for fire and smoke protection doors (and Invers)

ETS 42-R¹⁾

ETS 64-R

ETS 64-R (GSD)

ETS 64-R IRM

ETS 64-R IRM (GSD)

Slide rail for ETS

GS-ETS 620-ÖB²⁾

GS-ETS 830³⁾

Normal arm for ETS

NG-ETS 250⁴⁾

NG-ETS 400⁵⁾

R = Fire protection, GSD = Version with slide rail pushing (BG transom installation), GSZ = Version slide rail pulling (BS-normal installation), IRM = Integrated smoke detector, NG = Version with standard arm pushing (BG transom installation), SRI = Integrated closing sequence control


1) From 2020 **2)** Type of installation GSZ or GSD (up to 30 mm lintel depth / fire protection door) **3)** Type of installation SZ, GSD or leaf installation (up to 200 mm lintel depth / no fire protection door) **4)** For lintel up to 250 mm (fire protection door) **5)** For lintel up to 400 mm (not fire protection door)

Double-leaf drives ■ for fire and smoke protection doors

Types of doors



Tests / standards



ETS 64-R IRM-SRI

Double-leaf drives for fire protection doors (complete sets)

ETS 64-R IRM-SRI (NG)
ETS 64-R IRM-SRI (GSD)
ETS 64-R IRM-SRI (GSZ)

Double-leaf drives for standard and external doors

ETS 42-2
ETS 73-2

CABLE CLUTTER – WHERE'S THE MISTAKE?

We won't leave you alone.


From now on, you'll always have him by your side,
the functional ECO **ETS** – Assembly Buddy.

And if we were not able to answer all your questions,
please do not hesitate to contact us.

Your ECO contact for
intelligent door management

📞 +49 2373 9276 - 899


✉️ eco-service@eco-schulte.de



SHORT MANUAL ETS 73 AND ETS 64

1. Position the motor plug


Depending on the application (mounting variant) the position of the motor plug must be adapted. See table:



2. Force of the closing spring

The right preload of the spring (measure X) must be adjusted according to the table!

| Standard drive | | | | | |
|----------------------------------|-------|---------|---------|---------|---------|
| EN-Class | EN 3 | EN 4 | EN 5 | EN 6 | EN 7 |
| Leaf width | 950mm | 1.100mm | 1.250mm | 1.400mm | 1.600mm |
| Closing torque 0...4° | 18Nm | 26Nm | 37Nm | 54Nm | 87Nm |
| Standard arm | | | | | |
| Measure X* | 37mm | 34mm | 29mm | 23mm | 20mm |
| Sliding rail pull | | | | | |
| Measure X* | 34mm | 30mm | 23mm | 15mm | 12mm |
| Sliding rail push | | | | | |
| Measure X* | 32mm | 29mm | 22mm | 14mm | 12mm |




* Measure X is an approximate value for lintel depth 0mm. The force that is needed to open a door manually must not exceed 150 Nm. The force has to be measured as a static force on the main closing edge (right angle to the door leaf) in a height of 1.000mm ± 19mm.









3. Area for the latching function

The mechanical latching speed can be adjusted via Poti (on the board, blue).

Important! the door has to close safely when it is currentless. Raise the latching speed if needed (see point 2).



4. Mounting variants

| DIN left | | DIN right | |
|--|---|--|--|
| Lintel mounting |  | Lintel mounting |  |
| STANDARD pushing: plug position = Y | INVERSE: plug position = X | STANDARD pushing: plug position = Y | INVERSE: plug position = X |
| Lintel mounting |  | Lintel mounting |  |
| STANDARD pulling: plug position: X | INVERSE: plug position = Y | STANDARD pulling: plug position = X | INVERSE: plug position = Y |
| Lintel mounting |  | Lintel mounting |  |
| STANDARD pushing: plug position = Y | INVERSE: plug position = X | STANDARD pushing: plug position = Y | INVERSE: plug position = X |
| Leaf mounting |  | Leaf mounting |  |
| STANDARD pushing: plug position = Y | INVERSE: plug position = X | STANDARD pushing: plug position = Y | INVERSE: plug position = X |

SHORT MANUAL ETS 73 AND ETS 64

5. Commissioning

Procedure

1. Switch on drive on the side cap (Power-up).
First acknowledge the fire alarm for the fire protection variants.



2. Adjust display direction via joystick: Move down the joystick once ⇒ display direction turns into readable position.

Press
Down

3. Adjust linkage type Rod:
Move joystick left / right (see parameter chapter 7.1).
Confirm the right linkage type with OK: Shortly push the joystick in resting position.

Rod
STD-PH

4. Adjustment of the distance dAxis (Distance in cm between rotation axis of the hinge and the drive's mounting level ⇒ see illustration below)

Note:

dAxis is a reference value. dAxis must be adapted to the mounting circumstances.

dAxis
5 cm

5. Adjust opening angle Ao and confirm via OK.



Attention:

Steps 4 and 5 are affected by the mounting measures to the hinge.

Ao
95°

6. If available:
Chose low energy (low energy operation) and confirm via OK.
If low energy: Adjust leaf width and weight and confirm with OK.

Low En
OFF

Width
85cm

Weight
75kg

7. Adjust opening speed Vo and confirm with OK.


Vo
6

8. Adjust closing speed Vc and confirm with OK.

Vc
4

9. If required:
Adjust inverse operation (opening by spring force) and confirm with OK.

Invers
OFF



Procedure

10. Chose set up procedure (Teach) and confirm with OK.

Teach

11. Start the set up procedure (Teach) and confirm with OK.

Teach
ok?

12. The set up procedure starts automatically after 10 seconds (or directyl by moving the joystick ⇐⇨⇩⇧, without OK). The drive beeps during the set up process.

Following learning trip is made:

- Inverse: First, the closed position is searched at creep speed.
- Creep speed in opening direction
- Creep speed in closing direction

Teach1
x E10

Teach2
x E10

13. The following message is displayed at the end of the learning trip:

Done !
x E11

14. Display should now show the following:
E11 shows that the set up process is not yet finished.

>##<
 E11

15. Use the opening command to open and close the door leaf. This opens and closes at normal speed (withouth obstacle detection).

Note: Door leaf must not be obstructed.

Display should now show the following: The set up process is now complete.

>##<
 E11

Note:

A new set up process is necessary if:

- the spring tension was changed
- the leaf weight was changed
- the linkage type was changed
- the opening angle A_o was changed
- the Teach was obstructed before 20° opening angle
- the axis distance (dAxis) was changed
- the parameter inverse was changed.

SHORT MANUAL ETS 42


1. Mounting drive

1. For standard arm RS and Slide rail RG pushing:

For standard arm RS and Slide rail RG pushing: Hang the drive module (with designation PUSH pointing to chassis profile (B)) on the two pre-assembled screws (C). The position of the control unit (E) must be adjusted accordingly in advance.

2. For Slide rail pulling:


Hang the drive module (with designation PULL pointing to chassis profile (B)) on the two pre-assembled screws (C).



2. Adjustment Closing force spring and Poti

The closing spring (B) is preloaded to dimension $X=300$ mm on delivery. In exceptional cases, the spring tension (Dimension X) can be adjusted between 300 mm and max. 267 mm (without pre-assembled linkage).

Note: The correct closing spring preload must be set before the automatic setup procedure! In general, the closing spring of the standard drive can be set weaker. Any existing door lock must close correctly. Otherwise adjust closing spring preload or latching speed dampin (potentiometer) accordingly.




3. Latching speed

If the system is in a currentless condition or in MANUAL mode, the motor acts as an attenuator and leads to an even closing speed until the closed position is reached.

So that the door leaf can be opened and closed in currentless condition or falls into the door lock reliably


in the MANUAL operating mode, the drive is equipped with a slam function. The potentiometer can be used to adjust the motor damping (shortly before the close position) so that the compression spring exerts sufficient force to push the door leaf into the door lock.

4. Control print



5. Operating modes

The following operating modes can be selected using the program selection switch (A):



AUTOMATIC (I)

- Automatic opening via opening elements inside/outside + Key.
- Automatic closing after the adjustable hold-open time has elapsed.

HAND (0)

- The drive and the operating elements are switched off
- The door leaf can be opened manually
- The door leaf is closed from every position by spring force (Inverse = Spring opening, if not locked)


OFFEN (II)

- The door leaf opens automatically and stays in OPEN-position.

CABLE PLAN

ECO ETS 64-R


WITH 24V/48V SIGNAL



CABLE PLAN


ECO ETS 73

OPTIONAL PRINT




CABLE PLAN ETS 73 • ETS 64 • ETS 42

BEA 4 SAFE (SENSOR BAR)



CABLE PLAN ETS 73 • ETS 64 • ETS 42

BEA Flatscan LZR (LASER SENSOR)




CABLE PLAN

ETS 73 - ETS 64 - ETS 42

ESCAPE ROUTE TERMINAL "OFFLINE"

WITH **ETS**, MOTOR LOCK AND SURFACE HOLDING MAGNET




* Accessorie R2U-24 is required for this solution.

CABLE PLAN

MOTOR LOCKS


WITH DIRECT CONNECTION OF THE COIL



CABLE PLAN

MOTOR LOCKS


WITH OWN EVALUATION CONTROL



CABLE PLAN

MOTOR LOCKS


WITH SEPARATE EVALUTATION CONTROL AND POWER SUPPLY



OPERATION

Modes of operation

Following modes of operation are choosable via program selection button.



AUTOMATIC

Automatic opening via opening elements inside / outside + Key.
Automatic closing after the adjustable hold open time.



NIGHT

The door leaf only opens via the opening element Key (Key switch outside)



OPEN

Door leaf opens automatically and remains in the OPEN-position.



HAND

The drive and the control elements are switched off.
The door leaf can be opened manually.
The door leaf is closed from every position via spring force (Invers = Spring opening, if not locked)



EXIT

The door leaf only opens via opening elements inside and Key



Set up process (Teach)


Close the door leaf completely (Inverse = open). Push the buttons HAND and EXIT together for at least 5 seconds. All mistakes are deleted and the set up proces starts.

Settings

The parameters can be changed via display and joystick on the control device.



The movements of the joystick have the following effects:

- Move joystick straig up/down:
⇒ Scroll through display
- Move joystick horizontal to the left/right:
⇒ Change settings
- Shortly push the joystick in resting position:
⇒ Confirm: OK
- Joystick combination ⇐ ⇐ ⇐ ⇐ ⇒ ⇒
Open passwort protected areas



CONNECTIONS

| Product | Connections | | | | Illustration |
|--|--|---------------------|--------------------------------|---------------------|---|
| E-Strike (FS/RS) | Terminals 27-30 Currentless locked | | | |  |
| E-Strike E-Strike for escape routes | Terminals 27-31 Currentless unlocked | | | |  |
| Dead bolt switch contact (RSK) | NC contacts from RSK to terminals 28 and 32 In the "Config menu" set EL-FB to N.C. If the lock is locked, ETS does not start. | | | |  |
| Contactless surface button (BFT) | Opening command inside | | Opening command outside | |  |
| | ETS | BFT | ETS | BFT | |
| | 13 | blue | 10 | blue | |
| | 12 | purple | 9 | purple | |
| | 13 | brown | 10 | brown | |
| 11 | red | 8 | red | | |
| Contactless motion detector (Magic Switch) | Opening command inside | | Opening command outside | |  |
| | ETS | Magic Switch | ETS | Magic Switch | |
| | 13 | Power - | 10 | Power - | |
| | 11 | Power + | 8 | Power + | |
| | 13 | COM | 10 | COM | |
| 12 | NO | 9 | NO | | |
| Radar | Opening command inside | | Opening command outside | |  |
| | ETS | Radar | ETS | Radar | |
| | 11 | 1 | 8 | 1 | |
| | 13 | 2 | 10 | 2 | |
| | 13 | 3 | 10 | 3 | |
| 12 | 4 | 9 | 4 | | |

| Product | Connections | | | Illustration | |
|---|-------------------------------|----------------------|--------------------------------------|---|--|
| Control panel Bedix | ETS | Bedix | Cable specification |  | |
| | 6 | 4 | shielded cable U72M or | | |
| | 7 | 3 | EIB-Y(St)Y 2x2x0,8 mm, twisted wires | | |
| Note: Always use a separate cable for the Bedix and connect all wires. Double if necessary | | | | | |
| Radio transmitter and receiver for rocker large surface button (GFT) | Transmitter | GFT | Receiver | ETS |  |
| | blue | black (COM) | + (1) | 1 (24V) | |
| | brown | blue (N.O) | - (2) | 3 (GND) | |
| | | | COM (3) | 3 (GND) | |
| | | | N.O (5) | 2 (KEY) | |
| Teach in transmitter / receiver: | | | | | |
| <ol style="list-style-type: none"> Set the receiver to operating mode 3: Push programming button 3 x approx. 1 sec. until the LED flashes as follows: 3 x short - break - 3 x short Keep the transmitter / button (GFT) pressed until the LED on the receiver shows 4 sec. continuous light, then the LED flashes again. Now release the button (GFT) (this transmitter is now taught-in). Same procedure for other transmitters / buttons as above (pos. 2). Press the programming button on the receiver once = operating mode, LED off. Test the function on the GFT, blue LED must be lit on the ETS. Light up = opening command. | | | | | |
| Any opening button (ECO GFT, ER GFT etc.) | Opening command inside | | | | |
| | ETS | Button | | | |
| | 12 | NO | | | |
| | 13 | COM | | | |
| Key switch ST-02-UP (HPZ) At switch position 0 (standard) "automatic (all control elements) is active. At switch position 1, one of the following functions can be selected. | Key switch | ETS-Functions | | | |
| | | Night (Key) | Hand (manual) | One way (only OEI) | |
| | | COM | 26 | 26 | 26 |
| | | NO | 23 | 24 | 25 |
| | | NC | 22 | 22 | 22 |

SETTINGS

DRIVE PARAMETERS (PARAMETER)

| Parameter | Description | Setting range | Default |
|-----------|---|--|---|
| Vo | Velocity open (velocity open) | 0...14 (5...50%/s) | 6 |
| Vc | Velocity close (velocity close) | 0...14 (5...0%/s) | 4 |
| TOEx | Hold open time opening element inside/outside (time hold opening element inside/outside) | 0...60 s | 3 s |
| TKey | Hold open time Key (time hold opening element Key) | 0...180s | 5 s |
| TDelay | Start-up delay (time delay lock) | 0,0...4,0 s | 0,2 s |
| FDelay | Relief force when unlocking (force delay), only works if TDelay is >0. | 0,0...7,0 A | OFF |
| TLock | Door hold-up time (time press close) | 0,0...4,0 s | 0,5 s |
| FLock | Pressing force while locking (force lock), only works when TLock is >0. | 0,0...7,0 A | 2,0 A |
| FSlam | Slam function (force slam) | 0...10 | OFF |
| FWind | Obstacle detection optimised for external doors. (force wind) | OFF OPEN CLOSE BOTH | OFF |
| Fo | Opening force (force open) | 0...9 | 4 |
| Fc | Closing force (force close) | 0...9 | 4 |
| Foh | Hold open force (force open hold) | 0...9 | 0 |
| Fch | Locking force (force close hold) => automatically sets FLock and FDelay if they are 0 | 0,0...3,5 A | 0 |
| Ao | Opening angle of the door (angle open) If the opening angle is changed in the OPEN mode, the operating mode must be changed to HAND to close the door. | 20...(190°) Rod dep. | 95° * |
| Rod | Linkage types (Rod) | Standard arm pressing Sliding rail pulling Sliding rail pushing Leaf mounting pushing Without linkage pushing Without linkage pulling | STD-PH SLI-PL SLI-PH WIN-PH DIR-PH DIR-PL STD-PH * |
| Invers | Inverse-Application: In case of power failure/error, the door leaf is opened from any position by spring force (if not locked). Position of the motor plug is reversed to the standard drive. The electric lock/holding magnet must be connected in reverse to the standard drive (see wiring diagram E4-0141-713). | OFF ON | OFF * |
| dAxis | Distance between door hinge rotation axis and the drives mounting level (distance Axis). dAxis is a guide value. Depending on the mounting situation, dAxis must be adapted accordingly. | -8...+25cm Rod dep. | 0/+8cm Rod dep. * |
| Fos | Limitation of the opening force. Must not be increased in Germany! | 5...14 A | 5 A |

* Note: A new set-up process (Teach) is required.



SETTINGS

MULTI-LEAF SYSTEMS (DOUBLE DOOR)

| Parameter | Description | Setting range | Default |
|-----------|---|---|---------|
| DubleD | Roll for closing sequence control (Master/Slave) and Sluice-side (A/B) | OFF MastrA SlaveA MastrB SlaveB | OFF |
| AoSeq | Opening sequence delay angle (slave) (only visible if DoubleD is active) | 0...110° | 20° |
| AcSeq | Closing sequence delay angle (Master) (only visible if DoubleD is active) | 0...110° | 20° |
| InterL | Sluice | OFF SideA SideB | OFF |
| ILAuto | Sluice operating mode AUTOMAT (only visible if InterL is active) | Inacti Active | Active |
| ILExit | Sluice operation mode EXIT (only visible if InterL is active) | Inacti Active | Active |
| ILNigt | Sluice operating mode NIGHT (only visible if InterL is active) | Inacti Active | Active |
| ILType | Safety: Two doors work as a sluice (in all operating modes). The second door only opens if the first one is closed. Has to be set on both doors. Spital: Automatic sequence -> When an opening command is given, the door that receives the the opening command is opened. After this door is closed again, the second door opens automatically. NL: The second dor only opens if the first one is closed or when the override time runs out. | Safety Spital NL | Safety |
| TOverd | Only visible in ILType NL When the override time runs out, the sluice function is cancelled. As soon as both doors are closed, the sluice function is switched on again. | OFF 1...60s | OFF |
| RdrOEI | OFF: Radar OEO/OEI switches normally, door closes when both are inactive. ON: With OEO the (OEI) radar inside the sluice is masked out, so that it won't hold oben the door in tight sluices. | OFF ON | OFF |
| ILCdRc | Acitve: The opening commands are buffered and executed when the second door is closed. Inactive: The opening commands are only accepted and executed as soon as the second door is closed. | Active Inacti | Active |

SETTINGS CONFIGURATION (CONFIG)

| Parameter | Description | Setting range | Default |
|-----------|--|---|----------------------|
| Servo | Support for manual opening. KEY opens automatically. Adjustable in 5 steps, depending on leaf width and leaf weight. | OFF 1...5 | OFF |
| APuGo | Release angle Push&Go (angle push & go) | OFF, 2...10° | OFF |
| ASES | 1) Blanking point Safety Element Stop (angle safety element stop). ASES will be set to Ao automatically if Ao is changed. | 45°...Ao | 95° Ao dep. (95°) |
| ASER | 2) Blanking area Safety Element Reversing (angle safety element reversing). | 0...60° | 0° |
| SeOpCo | Obstinate opening (safety element open continue). After a Safety Element Stop while opening, the door should continue opening (instead of closing) as soon as SES is inactive. | OFF ON | OFF |
| SeOpTi | Waiting time until the drive despite SeOpCo = ON (safety element opening time) Closes if an obstacle blocks the door (only visible when SeOpCo = ON). | PERMAN 1...60s | 20s |
| SESClo | Safety Element Stop while closing active/inactive (safety element stop closing) | ACTIVE INACTI | INACTI |
| EMY-IN | Configuration of Emergency-Clamp (Opener contact) (emergency input) | CL-SPR (spring) STOP OPEN CL-MOT (motor) | CL-SPR |
| OExStp | Step-switch function (opening element step) | OFF OEI OEO KEY RADIO | OFF |
| FPReset | Acknowledgement of the fire alarm via fire alarm center (only allowed if the door is in visual range of the fire alarm center) | OFF ON | OFF |
| RC 0.1 | Parameterizable relays output 1 on option print 1 (relay contact) (only visible if relais print 0 is plugged in) | | CLOSED |
| RC 0.2 | Parameterizable relais output 2 on option print 1 (relay contact) (only visible if relais print 0 is plugged in) | CLOSED OPENING OPEN | OPEN |
| RC 0.3 | Parameterizable relais output 3 on option print 1 (relay contact) (only visible if relais print 0 is plugged in) | CLOSING ERROR ERROR | ERROR |
| RC 0.4 | Parameterizable relais output 4 on option print 1 (relay contact) (only visible if relais print 0 is plugged in) | PSAUTO PSNIGHT PSEXIT | GONG |
| RC 1.1 | Parameterizable relais output 1 on option print 2 (relay contact) (only visible if relais print 1 is plugged in) | PSOPEN PSMANU | OPENING |
| RC 1.2 | Parameterizable relais output 2 on option print 2 (relay contact) (only visible if relais print 1 is plugged in) | GONG LOCKED SIX30S | CLOSING |
| RC 1.3 | Parameterizable relais output 3 on option print 2 (relay contact) (only visible if relais print 1 is plugged in) | FP_RDY EMY_AL | PSAUTO |
| RC 1.4 | Parameterizable relais output 4 on option print 2 (relay contact) (only visible if relais print 1 is plugged in) | | LOCKED |



| Parameter | Description | Setting range | Default |
|-----------|---|--|---------|
| Unlock | Impulse/permanent unlock (impulse unlock) | IMPULS PERMAN | IMPULS |
| UnloCl | Retract (unlock) the motor lock before closing and lock it when the door leaf is closed. | INACTI PERMAN | INACTI |
| EL-Fb | Feedback of electronic lock (electric lock feed back) N.O. ⇔ Contact open when unlocked (-), closed if locked (+) N.C. ⇔ Contact open when locked (+), closed when unlocked (-) (+) and (-) show the state in diagnostic-menu. | OFF N.O. N.C. | OFF |
| LockAU | Operation mode AUTOMAT locked (locked automat) (only visible when Unlock = Perman) | UNLOCK LOCK | UNLOCK |
| LockEX | Operating mode AUSGANG locked (locked exit) (only visible when Unlock = Perman) | UNLOCK LOCK | LOCK |
| LockMA | Operating mode HAND locked (locked manual) (only visible when Unlock = Perman) | UNLOCK LOCK | UNLOCK |
| LcdDir | Orientation display (LCD direction) | 0...1 | 0 |
| MovCon | Permanent test Open/Closed (moving continuous) | OFF ON-FLT ON-PRM | OFF |
| OExMAN | Accepting open-commands when the door was opened manually (only when APuGo = OFF) (opening element inside/outside manual) | OFF ON | OFF |
| OEOSIR | Security element on hinge-opposite side as opening element. Note: For teaching the LZR-FLATSCAN this parameter must be switched off. | OFF ON | OFF |
| PSKIze | Zero position of the program position (operating mode); fixed program position, which can only be changed via terminals on the controller (program selection button in theSide cover inactive). Use for external program switch (only four terminals) or control of the program positions via terminals on the controller. (program selection terminal zero) | NO ACT PSOPEN PSHAND PSAUTO PSEXIT PSNIGT | NO ACT |
| SCBloc | Locking the program selection button in the side cover (side cover block) Toggle = lock / unlock (press active program key for at least 5 seconds). Time = Lock (automatically after 5 minutes without pressing the program buttons), Unlock (press the active program button for at least 5 seconds). | OFF TOGGLE TIME | OFF |
| Buzzer | Buzzer signals door leaf movement (persons with visual impairment/accessibility) | OFF BOTH OPEN CLOSE | OFF |

ERROR CODES (DISPLAY)

MISBEHAVIOUR WITH ERROR-NO

Drive

| No. | Description | Cause | Solution | Testing time | Reaction | | | | | |
|-----------|---------------------|---|---|--|--|----------------|---|---|-----------------|---|
| E1 | 03 Encoder | Canal A + B lost | <ul style="list-style-type: none"> ▪ Check encoder connection ▪ Check motor cable ▪ Rotation direction of the motor doesn't correspond with the linkage. ▪ Door is blocked ▪ Check if the Jumper is on X106 | While driving | H | | | | | |
| | | Short of A + B | | | | | | | | |
| | | Disruptions | | | | | | | | |
| | | Motor wire plugged wrong | | | | | | | | |
| | | No canal A | | | | | | | | |
| | | No canal B | | | | | | | | |
| | | No canal A + B | | | | | | | | |
| | | Short of A + B | | | | | | | | |
| | | E2 | | | | 01 Motor power | Power too high | <ul style="list-style-type: none"> ▪ Check motor cable ▪ Check if the Jumper is on X106 | Before starting | H |
| | | | | | | | <ul style="list-style-type: none"> ▪ Power too low ▪ Jumper missing | | | |
| E3 | 01 Damping | Test failed once | <ul style="list-style-type: none"> ▪ Set drive to operating mode HAND and cautiously try if the door closes with damping. ▪ If not, replace hardware ▪ If yes, check/correct friction of the door leaf and the closing spring preload. | Before closing, after starting up and then every 24 hours. | W Drive continues running, buzzer active. | | | | | |
| | | <ul style="list-style-type: none"> ▪ Test failed twice ▪ Damping defective or opening beyond heart curve peak | | | | | | | | |
| E4 | 01 Reference switch | Detected in open-position | <ul style="list-style-type: none"> ▪ Check the connection and switching point of the reference switch. ▪ Reference switch must be actuated in closed position (switching contact open). | Open position | F | | | | | |
| | | Not detected in closed-position | | Before the first set up ride | A | | | | | |
| | | Not detected in open-position | | | | | | | | |
| E5 | 00 Power limitation | <ul style="list-style-type: none"> ▪ Overload of the control ▪ Maximum power is limited | <ul style="list-style-type: none"> ▪ Check/correct friction of the door leaf and the closing spring preload. | Permanently | A | | | | | |

Operating

| No. | Description | Cause | Solution | Testing time | Reaction |
|------------|----------------------------------|---|--|---------------------------------------|----------------------------|
| E10 | 01 Fullteach required | Parameter Ao, Rod, Invers or dAxis changed | Proceed Teach | When changing the drive configuration | H |
| | 02 | Minimum opening angle not reached | Check locking/electronic lock | During the Teach | |
| E11 | 01 Halfteach required (Opening) | Parameter Vo changed | Proceed complete, unobstructed opening cycle | When changing the ride parameters | W |
| | 02 Halfteach required (Closing) | Parameter Vc or FSlam changed | Proceed complete, unobstructed closing cycle | | |
| E14 | 01 Locking/ Electronic lock | Door leaf sticks in the locking/ electronic lock. | Check function of locking/electronic lock | When opening from close-position | H |
| | 02 | Inverse-operation has no locking or locking force Fch is not adjusted | Adjust/increase locking force | At the end of the Teach | W |
| E15 | 01 Obstacle in opening direction | Too many obstacles encountered in a row | <ul style="list-style-type: none"> ▪ Check system ▪ Remove obstacle ▪ Move door leaf to target position | Permanently | H, A Restart after 60s |
| | 02 Obstacle in closing direction | | | | |
| E16 | 01 Temperature | Temperature on output range has reached 81°C | Observe the limits of use. | Permanently | A Drive running reduced |
| | 02 | Temperature on output range has reached 91°C | | | A Drive stands still |

ERROR CODES (DISPLAY)

FAILURE WITH ERROR NUMBER

Safety elements

| No. | Description | Cause | Solution | Testing time | Reaction |
|------------|-------------|------------------------------|--|----------------|----------|
| E20 | 01 SER Test | SER Test signal unsuccessful | <ul style="list-style-type: none"> SER short against ground Check wiring of sensor or bridge | Before closing | A |
| | 02 | SER too slow | <ul style="list-style-type: none"> SER reacts too slow Check wiring of the sensor Check for reverse polarity of test signal | | |
| E21 | 01 SES Test | SES Test signal unsuccessful | <ul style="list-style-type: none"> SES short against ground Check wiring of sensor or bridge | Before opening | A |
| | 02 | SES too slow | <ul style="list-style-type: none"> SES reacts too slow Check wiring of the sensor Check for reverse polarity of test signal | | |
| E22 | 01 EMY Test | EMY input to 24V | <ul style="list-style-type: none"> Check EMY bridge Check wiring on EMY | Permanently | H |

Power supply

| No. | Description | Cause | Solution | Testing time | Reaction |
|------------|----------------|---|--|--------------|-------------------------|
| E30 | 01 30V Error | 30V too low | <ul style="list-style-type: none"> power failure | Permanently | A |
| | 02 | 30V too high | <ul style="list-style-type: none"> Motor overload | | |
| | 03 | Error when switching on | <ul style="list-style-type: none"> Check power supply Replace hardware | | |
| E31 | 01 24V General | Error when switching on | Overload, short of the 24V-inputs (exclusive electric lock, Safety Elements) | Permanently | A Restart after 10s. |
| | 02 | Overvoltage/Undervoltage | | | |
| E32 | 01 24V Safety | Overvoltage/Undervoltage | Overload, short of Safety Elements | Permanently | A Restart after 10s. |
| E33 | 01 24V E-Lock | <ul style="list-style-type: none"> Error Overvoltage/Undervoltage | Überlast, Kurzschluss Elektroschloss | Permanently | A Restart after 10s. |
| | 02 | <ul style="list-style-type: none"> Early warning Overvoltage/Undervoltage | | | |
| E34 | 01 24V CAN | Overvoltage/Undervoltage | Overload, short of external supply CAN | Permanently | A Restart after 10s. |

System

| No. | Description | Cause | Solution | Testing time | Reaction |
|------------|----------------------|------------------------------------|--|--------------|-------------|
| E50 | 01...99 System error | Unexpected hard- or software event | <ul style="list-style-type: none"> ▪ Switch on/ off drive ▪ Perform factory reset ▪ Perform software update ▪ Contact manufacturer | Permanently | W or F or H |
| E51 | 01...99 System error | Unexpected hard- or software event | <ul style="list-style-type: none"> ▪ Switch on/ off drive ▪ Perform factory reset ▪ Perform software update ▪ Contact manufacturer | Permanently | W or F or H |
| E52 | 01...99 System error | Unexpected hard- or software event | <ul style="list-style-type: none"> ▪ Switch on/ off drive ▪ Perform factory reset ▪ Perform software update ▪ Contact manufacturer | Permanently | W or F or H |

Options

| No. | Description | Cause | Solution | Testing time | Reaction |
|------------|--------------------------|---|---|--------------|----------|
| E60 | 00 Relaisprint 0 | Option print has been removed, redirected or is defective | <ul style="list-style-type: none"> ▪ Check if option exists ▪ Falls If defective: Replace or remove from configuration ▪ Note: Deleting the error 60 ▪ => see mounting instruction ECO ETS (Chapter 13.7.1) | Permanently | W |
| | 10 Relaisprint 1 | | | | W |
| | 20 Radio print | | | | W |
| | 30 Fire protection print | | | | A |

Closing sequence control/Sluice

| No. | Description | Cause | Solution | Testing time | Reaction |
|------------|--------------------------|------------------------------------|--|--------------|----------|
| E70 | xx CAN-Bus-configuration | CAN-Address xx existing two times. | Define closing sequence or sluice roll correctly. | Permanently | W |
| E71 | 01 CAN-Connection | No CAN-Connection | <ul style="list-style-type: none"> ▪ Plug in, control or replace CAN-Cable ▪ Control if all CAN-Participants are switched on | Permanently | W |





ECO Schulte GmbH & Co. KG

Iserlohner Landstraße 89

D-58706 Menden

Telephone +49 2373 9276 - 0

Telefax +49 2373 9276 - 40

info@eco-schulte.de

www.eco-schulte.de

■ SYSTEM TECHNOLOGY FOR THE DOOR



GO DIGITAL

I'm also digital.

→ bit.ly/2MhlcAR

